



NOTE:

1. SET MAILBOX POST SO FACE OF MAILBOX IS AT BACK EDGE OF SHOULDER OR 8 INCHES BACK FROM FACE OF CURB FOR STREETS WITH CURBING.
2. CUT NOTCHES IN POST AND TOP RAIL TO FORM CROSS HALVING JOINT AND BOLT 2 PIECES TOGETHER.

Note: You may firmly secure your mailbox to the top rail.

TOWN OF ROCKPORT PUBLIC WORKS DEPARTMENT

Adopted from Town of Brunswick drawing
T. Mann design